

# Lighted Side Post Aluminum Patio Umbrella User Manual



**Vrienden Outdoor Living is a registered brand of M&E Sales, LLP**

**150 W 88th St #114  
Bloomington MN 55420**

**952.884.0326  
vriendenoutdoor@gmail.com**

Safety Information	02
Pre-Assembly	02
Assembly	03
Operation & Use	03
Warranty	04

## Safety Information

### USE CAUTION

Never leave this product in the open position overnight or while away. Weather conditions causing gusting winds could result in damage to this product. If you notice excessive swaying or movement in windy conditions, close the umbrella. Under no circumstances is the manufacturer responsible for any damage caused by or to the umbrella resulting from, but not limited to, any weather-related causes.

### READ BEFORE USE

Before using the umbrella, you must do the following:

- Install the chosen accessory base appropriately, according to the instructions *OR*
- Get four (4) 18"-20" patio stones (or similar) weighing at least 35 lbs each. Place one (1) patio stone on each of the four (4) sides of the umbrella's cross base legs. The total weight of all four (4) patio stones should be at least 140 lbs. You can use heavier stones if desired.


Before using the lighting system, you must do the following:

1. Insert the INPUT end of the transformer [part #118] into a 120V power supply.
2. Insert the OUTPUT end of the transformer [part #118] into a power socket.

## Pre-Assembly


**Fig 1**

- Inspect umbrella frame and all component parts before assembling. If there is any damage, take pictures and send to customer service.
- A. Umbrella Frame
- B. Vent Top Cap [part #033]
- F. Cross Base [part #100-101]
- G. Support Base [part #094]
- H. Rotating Base [part #096]
- I. Transformer w/ Power Cord [part #118]
- J. Light Globe [part #109] + Light Bulb [part #112]
- K. Cover for Rotating Base [part #095]



**Fig 2**

1. Install the upper cross base [F] to the lower cross base [F].
2. Mount the rotating base [H] to the top of the cross base with four (4) M8x30 bolts (included).
3. Attach the support base [G] to the rotating base with four (4) M8x20 bolts (included).
4. Install the vent top cap [B].
5. Slide the cover for the rotating base [K] over the support base.
6. Insert the umbrella frame [A] into the support base and tighten the thumbscrew.
7. Screw the light bulb [J] into the light socket, then screw onto the light globe [J].



**2**

## Operation & Use

**Fig 3**

### • Canopy Operation

- TO OPEN: Turn the crank [A] clockwise
- TO CLOSE: Turn the crank [A] counter-clockwise
- When storing the umbrella, use ties to secure the canopy


NOTE: When cranking, go slowly. If you feel resistance and the canopy is not opening, spread the umbrella ribs manually with your hands, then continue to crank. This will help avoid the ribs getting tangled and breaking.

### • Tilt Handle Operation

- Squeeze the tilt handle [B] and move it up or down to change the angle of the canopy

### • Light Operation

- (- -) turns the moonlight on bright and the star lights off
- (==) turns the moonlight on dim and the star lights on
- (o) turns the lights off



power switch




power socket

**3**

**Fig 4**

### • Rotating Base Operation

- Step on the foot pedal and rotate the umbrella by hand to the desired location
- Release the foot pedal to lock the umbrella in position



**4**

## ONE (1) YEAR - Frame & Fabric Warranty

The manufacturer warrants that this umbrella, when subject to normal and proper use, will be free from manufacturing defects for a period of one (1) year from the date of purchase. Should any defect occur during the specified time period, the manufacturer will repair the defective product, or provide replacement parts and components material, at its own option. Damage caused by wind/weather is not covered under this warranty. It is recommended to close the umbrella during inclement weather, high winds, or when not in use. The manufacturer also reserves the right to issue a full refund of the purchase price in lieu of repair or replacement. **This warranty is not transferable.** This warranty replaces all other oral or written warranties, liabilities or obligations of the manufacturer. Pertinent state law shall control for what period of time following the purchase a consumer may seek a remedy under the implied warranty of merchantability or fitness for a particular purpose. In no event shall the manufacturer be liable for consequential or incidental damages of any kind resulting from the breach of this warranty. Some states do not allow limitations on - or the exclusion of - incidental or consequential damages, so the above exclusions may not apply to you. This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

## Return Policy

You can return the product for a full refund, less shipping and 35% restocking fee, within 30 days from the date of delivery. Products bought at trade shows are final sale and not eligible for refunds. We will not refund damaged product. You are responsible for all shipping costs related to the return.

Vrienden Outdoor Living is a registered brand of M&E Sales, LLP

150 W 88th St #114  
Bloomington MN 55420



952.884.0326  
vriendenoutdoor@gmail.com

MADE IN CHINA

4 of 4